Programmable Logic Semi-Custom Full Custom

Skill Required	Little Lots	
Time to Market	Quick Slow	
One-off Manufacturing Cost	Cheap Expensive	
Unit Cost In Production	Cheap Expensive	
Speed	Fast Slow	
Area	Small Big	
Power	Low High	

All design styles need full custom designers A large ASIC (especially SoC) may mix Semi-Custom and Full Custom

8000